


LEGEND		
REQ	SYM	DESCRIPTION
2	O	OXYGEN OUTLET
2	A	AIR OUTLET
2	V	VACUUM OUTLET
2	E4	DUPLEX RECEPTACLE, 8300 RED, 20A, 125V, H.G., EMER. POWER
2	E2	DUPLEX RECEPTACLE, 8300 IVORY, 20A, 125V, H.G., NORMAL POWER
1	NC	NURSE CALL PROVISION
1	CB	CODE BLUE PROVISION
2	HC	HORIZONTAL ACCESSORY CHANNEL
QTY	ACCESSORIES NOT SHOWN (PER UNIT)	

- NOTES:**
- ① GAS OUTLETS TO BE MSC STANDARD BRAND WITH CONNECTION TO MATCH EXISTING HOSPITAL EQUIPMENT.
 - ② MEDICAL GAS CONNECTION LOCATION. MEDICAL GAS PIPING : TYPE L COPPER TUBING. AIR & OXYGEN - 1/2" I.D., VACUUM - 3/4" I.D.
 - ③ PANEL LAMINATE COLOR: TO BE DETERMINED. ALL EXPOSED METAL SURFACES WILL HAVE A SURF POWDER COATED FINISH.
 - ④ INTERIOR STUD FRAMING TO FIT A 3-5/8" METAL STUD WALL WITH ONE LAYER OF 5/8" GYPSUM BOARD FINISH.
 - ⑤ JUNCTION BOXES: J1--NORMAL POWER, J2--EMERGENCY POWER, J3--NC/CB/S5.



MODULAR 500 EAST BRITTON ROAD
SERVICES COMPANY OKLAHOMA CITY, OK 73114


REVISD

DATE

DRAWN BY

DRAWING #

SILHOUETTE® III
SEMI-RECESSED
MODEL 8510

SCALE:  = 1'

PB-195

PROJECT

